

# Instructions for automatic operation

**green lamp "Automat frei" must be on** (when the doors are closed)

**Load your luggage: No material outside of the luggage baskets**  
(danger of collision)

**Close the cabin door** (without getting in)

**Insert the coin in the  
automatic device on the right**

**Insert your chip card to the  
reader**

**Press "Fahrpreis abbuchen" and  
remove the card**

**Enter the cabin and close the door**

**In the cabin press "Ich will zur Mittelstation"** (if you want to go to the middle station) **or "Ich will zur Bergstation"** (if you want to go to the mountain station) **until the cable car leaves**

**In case of malfunction, please contact: +41 (0) 079 566 60 94 or  
+41 (0)79 692 43 78**